



Memory Upgrade for Apple iBook Installation Guide



This Product is backed by a Limited Lifetime Warranty.
For complete warranty information visit www.edgetechcorp.com/register

The iBook has one expansion slot for RAM. To access this slot, the user may perform the following operations.

Important: Like most electrical components inside computers, memory is susceptible to damage by static electricity. NEVER handle memory or computer parts if you have any static electricity build up. Before working with any sensitive electronics, be sure to touch a large metal object to ground yourself. If you have an antistatic grounding strap, it's a very good idea to use it while working with your computer.

1. Unplug the computer's AC adapter.
2. Remove the computer's battery.
3. Unlock the keyboard by turning the slotted screw, which is part of the Num Lock LED located between the F4 and F5 keys. Turn the screw 180 degrees to unlock the keyboard. NOTE: The locking screw may already be unlocked.
4. Release the two latches which are located at the top of the keyboard. One latch is between the ESC key and the F1 key, while the other is between the F8 and F9 keys. (The user can release the latches by sliding them toward the front of the iBook.)
5. Lift the keyboard up and turn it over. Do this without disconnecting the keyboard's membrane cable.
6. Remove the AirPort Card if present, by unlatching the formed wire holder on the module and then pulling the flex tab to remove the module. The antenna cable should remain attached to the memory module.
7. Remove the two screws securing the perforated metal RAM door with a Phillips head screwdriver. The screws are located to right of the wireless LAN module.
8. Slide the perforated metal RAM door towards the back of the compute, then lift it up and out of the iBook.
9. Align the notches of the new memory module and the expansion connector. The module inserts at a 45 degree angle and then pushes down until the side holders clicks into place.

Once the RAM expansion module has been installed in the slot, the user must reassemble the computer by performing these steps in reverse order.

IMPORTANT

PLEASE CONTACT A QUALIFIED TECHNICIAN FOR ASSISTANCE IN INSTALLING OR USING THIS PRODUCT IF YOU ARE NOT FAMILIAR WITH DOING SO. ANY INSTRUCTIONS INCLUDED WITH THE PRODUCT ARE FOR CONVENIENCE ONLY AND ARE NOT INTENDED TO BE ALL-INCLUSIVE.

